



# FLOW-3D Quick Start Guide

1. Start the installer by double-clicking the executable.




2. Continue through the installation, ensuring License Server is selected in the Features dialog box.



3. Once the installation has completed, copy the license file *flow3d.lic* into the installation's licenses directory.

This directory can be recognized as license server executables, such as *lmtools.exe* and *F3DTKNUX.exe*, are contained within it. The default PATH to this directory is *C:\flow3d\v11.2\licenses*. If a different PATH was chosen during installation, use that path instead.



4. Finally, start the license server using LMTOOLS, either by double-clicking it from the "licenses" directory, or by using the entry in the Windows Start Menu.
5. Click the Start/Stop/Reread tab in LMTOOLS and click "Start Server" -- then, run **FLOW-3D**.

