



FLOW-3D®


Quick Start Guide

1. Start the installer by double-clicking the executable. 
2. Continue through the installation, ensuring License Server is selected in the Features dialog box.




3. Once the installation has completed, copy the license file *flow3d.lic* into the installation's "licenses" directory.

This directory can be recognized as license server executables, such as LMTOOLS.exe and F3DTKINUX.exe will be present. The default PATH to this directory is c:\flow3d\v12.0\licenses. If a different PATH was chosen during installation, use that PATH instead.



4. Finally, start the license server using LMTOOLS, either by double-clicking LMTOOLS.exe within the “licenses” directory, or by clicking it in the Windows Start Menu.



5. Click the Start/Stop/Reread tab in LMTOOLS and click the “Start Server” button – then, run **FLOW-3D**.

